

Exploued diagram and spare parts list (CD251)			nev.3
Machine	Explode	Code	Description
CD231 Buffalo Countertop Heated Food Display 687mm	1	*	Control Panel (old version)
CD231 Buffalo Countertop Heated Food Display 687mm	1	*	Control Panel (After 5078451-UK, After 22519-EU)
CD231 Buffalo Countertop Heated Food Display 687mm	3	AG815	Castor
CD231 Buffalo Countertop Heated Food Display 687mm	4-1	2	BS Plug (old version)
CD231 Buffalo Countertop Heated Food Display 687mm	4-2	*	Power Cord (old version)
CD231 Buffalo Countertop Heated Food Display 687mm	4-1	*	BS Plug (After 5078451-UK, After 22519-EU)
CD231 Buffalo Countertop Heated Food Display 687mm	4-2	~	Power Cord (After 5078451-UK, After 22519-EU)
CD231 Buffalo Countertop Heated Food Display 687mm	5-1	AF951	Temperature Thermostat
CD231 Buffalo Countertop Heated Food Display 687mm	5-2		
CD231 Buffalo Countertop Heated Food Display 687mm	5-3		
CD231 Buffalo Countertop Heated Food Display 687mm	6-1	~	Decoration Nut Gasket
CD231 Buffalo Countertop Heated Food Display 687mm	6-2	<u> </u>	Nut Gasket
CD231 Buffalo Countertop Heated Food Display 687mm	6-3	<u> </u>	Nut Decoration
CD231 Buffalo Countertop Heated Food Display 687mm	7	AD426	On/Off Switch
CD231 Buffalo Countertop Heated Food Display 687mm	8	AD426 AD427	Indicator Light
CD231 Buffalo Countertop Heated Food Display 687mm CD231 Buffalo Countertop Heated Food Display 687mm	9	AD427 AD428	Temperature Display
CD231 Buffalo Countertop Heated Food Display 687mm	10	AD429	Base Feet
CD231 Buffalo Countertop Heated Food Display 687mm	11	AK169	Door Metal Insert
CD231 Buffalo Countertop Heated Food Display 687mm	12	2	Door Glass
CD231 Buffalo Countertop Heated Food Display 687mm	13	AK170	Door Handle
CD231 Buffalo Countertop Heated Food Display 687mm	14	*	Left Pillar
CD231 Buffalo Countertop Heated Food Display 687mm	15	*	Right Panel
CD231 Buffalo Countertop Heated Food Display 687mm	16	*	Side Glass
CD231 Buffalo Countertop Heated Food Display 687mm	17	*	Left Panel
CD231 Buffalo Countertop Heated Food Display 687mm	18	AK171 AK172	Bottom Left Small Bracket
CD231 Buffalo Countertop Heated Food Display 687mm	19		Bottom Right Small Bracket
CD231 Buffalo Countertop Heated Food Display 687mm	20		Left Shelf Bracket
CD231 Buffalo Countertop Heated Food Display 687mm	21		Right Shelf Bracket
CD231 Buffalo Countertop Heated Food Display 687mm	22		Right Pillar
CD231 Buffalo Countertop Heated Food Display 687mm	23	~	Stainless Light Cover
CD231 Buffalo Countertop Heated Food Display 687mm	24	~	Curved Front Glass
CD231 Buffalo Countertop Heated Food Display 687mm	25	~	Sliding Glass Track
CD231 Buffalo Countertop Heated Food Display 687mm	26-1	AD729	Top Chrome Shelf 1
CD231 Buffalo Countertop Heated Food Display 687mm	26-2	AD421	Middle Chrome Shelf 2
CD231 Buffalo Countertop Heated Food Display 687mm	26-3	AD737	Bottom Chrome Shelf 3 (The Biggest)
CD231 Buffalo Countertop Heated Food Display 687mm	27	*	Sliding Door Track
CD231 Buffalo Countertop Heated Food Display 687mm	28-1	AD430	U-Shaped Heating Element (Old version)
CD231 Buffalo Countertop Heated Food Display 687mm	28-1	AF497	U-Shaped Heating Element (From PO169485)
CD231 Buffalo Countertop Heated Food Display 687mm	28-2	AF887	Bracket For Heater
CD231 Buffalo Countertop Heated Food Display 687mm	29	AF886	Chassis Of Heater
CD231 Buffalo Countertop Heated Food Display 687mm	30	*	Heater Brace
CD231 Buffalo Countertop Heated Food Display 687mm	31	~	Radiator Bottom Plate
CD231 Buffalo Countertop Heated Food Display 687mm	32	~	Water Box
CD231 Buffalo Countertop Heated Food Display 687mm	33	*	Stainless Housing
CD231 Buffalo Countertop Heated Food Display 687mm	34	~	LED Light
CD231 Buffalo Countertop Heated Food Display 687mm	35	*	Socket
	1		<u> </u>

Exploded diagram and spare parts list (CD231) Rev.9

CD231 Buffalo Countertop Heated Food Display 687mm	36	2	Side Board Of Light Cover
CD231 Buffalo Countertop Heated Food Display 687mm	37	AF955	T1M/33 Control 150°C/Thermal Cut-out
CD231 Buffalo Countertop Heated Food Display 687mm	38	AF954	T1/33 Control 125°C/Thermal Cut-out